

WARRANTY



This product, 12V101, is warranted to be free of defects in materials and workmanship for one year from the date of purchase. This warranty is non-transferable and only applies to the original purchaser of 12V101. This warranty does not cover any amount of damages in excess of the retail purchase price of the product under any circumstances. Incidental and consequential damage are specifically excluded from coverage under this warranty.

RETURN POLICY:

Defective products may be returned postage prepaid to VersaDri, LLC. Any returned product must come with a copy of the original purchase invoice and a returned goods authorization number written on the outside of the mailer package. If the dryer 12V101 is returned within 30 days from the date of purchase, it will be replaced with a new MobilDri Portable Dryer free of charge. If the MobilDri Portable Dryer 12V101 is returned after 30 days from the date purchased but less than one year, VersaDri, LLC will, at its option, repair, recondition or replace the dryer free of charge. VersaDri, LLC reserves the option to replace the unit with a new or reconditioned MobilDri Portable Dryer of the same or comparable design. The repaired or replaced product will then be covered under the remainder of the original warranty. The warranty guarantee does not start over with the replacement, repaired or reconditioned product. During the warranty period, VersaDri, LLC will be responsible for the return shipping charges within the USA only.

NOTE:

If returning any product, send only the part that needs to be repaired or replaced.

LIMITATIONS:

This warranty does not cover damages due to misuse, abuse, alterations, lack of care, uses not intended for this dryer or failure to follow the instruction manual. This also includes damages from rain, wind, sun or other acts of nature. Disassembly, normal wear is not covered under the warranty.

STATE LAW RIGHTS:

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation or incidental or consequential damages. Check to find your rights on warranty in your state.

WARRANTY SERVICE REQUEST:

If sending your dryer for warranty or service, contact VersaDri, LLC at support@versadri.com for specific instructions. You will be instructed how and what to include or exclude and where to send it. You MUST have a return goods authorization number assigned by VersaDri, LLC. This number must be legibly written on the outside of the mailing package for processing. Always keep copies of paperwork for your records.


VersaDri, LLC
4034 Blake Ct
Dorr, MI 49323

Model # 12V101
Made In China

Find your Dri
and More @
versadri.com or
scan the QR Code



MOBILDRI PORTABLE DRYER



12V101 INSTRUCTION MANUAL

Thank you for the recent purchase of the 12V101 MobileDri Portable Dryer. We hope you are pleased with your purchase. If not please contact support@versadri.com. This instruction manual will give you tips for operating your dryer and tips to keep it working at its optimal performance. Once you have read and understand the information, we suggest you file this document away for future reference.

IMPORTANT: READ ALL SAFETY GUIDELINES BEFORE USE

▲ Notice and obey all safety messages that follow this symbol to avoid damage or potential injury.

SAFETY

- If the 12V101 purchased is damaged in shipment, contact VersaDri, LLC at support@versadri.com
- Do not use the 12V101 for anything other than its intended use.
- Do not leave the dryer unattended while operating and unplug the unit when not in use.
- Do not attempt to fix the dryer if damaged. Contact support for information on restoration or replacement.
- Do not use in settings where weather, moisture or debris could penetrate the unit.
- Do not use in a place that could inhibit operation of a vehicle.
- If the unit shows damage or makes unusual noise, unplug and do not try to fix the unit. Refer to trouble shooting and/or contact support.

▲ CAUTION:

Do not attempt to dry saturated items before wringing the excess liquid out. Gear that needs drying cannot be so wet as to drip on or into the internal components.

▲ WARNING:


Do not attempt to dry chemically soaked gear or items that could contain a substance when saturated or vaporized could be flammable or dangerous if inhaled.

MOBILDRI CARE

- To clean the unit, use a damp sponge or cloth. DO NOT submerge or saturate the unit in water or any liquid. Do not let any liquid filter into the internal components when cleaning or at any time. If unit accidentally becomes saturated, call support for instructions on how to restore or replace your product.
- Do not wash with any chemical. Some chemicals can permanently damage plastics. This could also affect the function of the unit and void the warranty

TROUBLESHOOTING

Dryer will not run or shuts off automatically



Good Fuse Replace Fuse

- Check to see if your Auto ignition key is turned on. Most vehicles will not supply power unless the ignition is in the accessory position or running.
- Some ports do not seat the plug well or is not a compatible size, check to see if the plug is fully inserted and making proper connection. If the plug is inserted and power is on, the LED will be lit on the dryer to show power is going to the unit.
- Inspect the power cord and switch for damage.
- The DC cord has an in-line fuse. Check this fuse to see if the fuse has failed, if there is a gap in the filament then change the fuse with exactly the same amperage fuse.
- Your "Vehicle" fuse can blow if it spikes or is overloaded. Check the fuse that powers the port you plug the dryer into and replace if needed. See vehicle manual for location and procedure.
- This unit has a thermal safety switch. This turns the unit off when heat exceeds set limits.
- It may shut-off when warm air is trapped by a tight glove at the wrist or improper circulation. Let the unit cool then when cool will reset automatically. Test w/out covering the tubes.

DC plug gets very warm

- Through normal vibration in a vehicle, the DC plug can back away from the contact. Push the plug into the port and check frequently. If this becomes a chronic problem, contact support.

Dryer makes noise or smells unusual

- The Dryer may collect debris inside. That debris can bounce on the fan or collect on the heater. Unplug the unit and turn upside down and shake vigorously to dislodge any debris.
- If the fan is distorted it can bind and make noise. Look for crush damage. If the unit shows any damage or damage is suspected, contact support for information on how to correct the issue.


Dryer does not perform according to claim

- The dryer must have circulation for airflow to move in and out of the item being dried. Reposition the item being dried on the tubes where air flow could be blocked.
- Make sure the air intake is not blocked. See diagram for location of air intake.


USING THE MOBILDRI UNIT

- The MobileDri Portable Dryer is designed exclusively to dry wet gear on the go with designated accessory tubes, including gloves, socks, shoes, boots, hats, helmets and more.
- After the dryer and accessories are removed from the packaging, ensure there is nothing that blocks the ports or tubes, check for any crush damage.
- Insert the DC plug into an accessory socket in your vehicle, turn the unit on each setting to test function.
- If output is venting on both sides, install the desired accessory tubes onto the ports.
- Place and secure the unit in a cup holder. The tubes rotate and/or to allow dash clearance and/or access to dash controls. Set the angle to your preference.
 - NOTE: Tubes do not have to point in the same direction to be equally effective.
- Thread items such as gloves, shoes, socks or helmets onto the appropriate tubes.
 - For example, using the GloveDri tubes, place wet gloves onto the dryer with thumbs toward the inner curve. Push the tube finger spacers in the three center fingers of the gloves.
- Allow cuff of the wet items to flare out. Do not tuck or close items around the tube and base mating area as circulation in and out of the wet gear speeds drying time.
- Unplug the unit when not in use.
- Do not leave unattended while in use or with small children while plugged in or in use.
- Keep all intake vents clear of any obstructions.
 - Air must flow freely for the unit to dry efficiently and not trip the excessive heat sensor.


MOBILDRI WITH GLOVE ATTACHMENT




DEPENDING ON THE PACKAGE PURCHASED, YOU MAY HAVE SOME OR ALL OF THE FOLLOWING:




GloveDri Tubes (gloves)



ShoeDri Tubes (shoes, socks, short boots)



BootDri Extension Tubes (use with ShoeDri for long boots)



HelmetDri with Y Tubes (hats and helmets)



Find your Dri and More @ versadri.com or scan the QR Code